

WCP320 SIG SAUER 9MM LUGER SEMI-AUTO HANDGUN - WCP320 SIG SAUER 9MM 4.7 BBL (2)17RD AGENCY TRIGGER BLACK

WCP320 SIG SAUER 9MM LUGER SEMI-AUTO HANDGUN Wilson Combat and Sig Sauer are pleased to announce the Wilson Combat enhanced P320 collaboration, the WCP320. This 9mm pistol includes Wilson Combat's custom P320 grip module (black or tan), P320 slide with X-TAC pattern serrations, and black DLC finish. Wilson Combat gunsmiths and engineers have completely reworked a SIG SAUER P320 chassis and unfinished SIG-manufactured slide into their ideal version of a high-performance, perfected striker-fired pistol. This robust, fast-handling pistol wears the Wilson Combat engineered polymer grip module. This newly designed and manufactured grip has enhanced traction, smoother reloading, improved pointability, and superb recoil control in dynamic shooting. This grip turns an already solid platform into an ergonomic shooting machine. The slide has been machined with the Wilson Combat X-TAC pattern for improved manipulation under stress. The front and rear cocking serrations, as well as the slide top, wear this signature Wilson Combat pattern. The stainless steel slide and chromoly barrel wear the most advanced black DLC (Diamond-like-Carbon) physical vapor deposition finish available. This finish has chromium and tungsten underlayers for long-lasting corrosion and abrasion resistance. FEATURES: Wilson Combat P320 Carry grip module (Black) Wilson Combat X-TAC P320 slide with machine bevels Black DLC finish on slide/barrel X-TAC pattern front and rear cocking serrations X-TAC pattern on slide top Carry cut Wilson Combat logo on slide Wilson Combat Battlesight with red fiber optic front sight SIG factory magazine release SIG factory slide Stop SIG P320 X-Full Size steel trigger OR Agency Arms Trigger 2 17 round X-Series magazines Beveled magazine well Rail for mounting light or laser Special serial number range with WC prefix SPECIFICATIONS: Cartridge: 9mm Luger Magazine capacity: 17 rounds Barrel length: 4.7" Overall length: 8.25" Sight radius: 6.7" Height: 5.5" Width: 1.5" Weight empty: 29.2 oz Weight loaded: 36.7 oz



Attributes

- Name: WCP320 SIG SAUER 9MM 4.7 BBL (2)17RD AGENCY TRIGGER BLACK
- Manufacturer: WILSON COMBAT
- Product no.: 100040633
- Mfr. No.: SIG-WCP320F-9BA
- Action Type: Striker Fired
- Barrel Length: 4.6"
- Capacity: 17+1-Round
- Finish: Black
- Front Sight: Fiber Optic
- Length: 7.9"
- Magazine Included: 2 x 17-Round
- Magazine Type: Removable
- Make: Sig Sauer
- Model: P320
- Muzzle: Plain
- Náboje: 9 mm Luger
- Rear Sight: Fiber Optic
- Safety: No
- Stock Material: Polymer

- Weight: 1.65 lbs
- Delivery weight: 1.928kg
- Shipping height: 76mm
- Shipping width: 279mm
- Shipping length: 394mm
- UPC: 810025503390

Item details

Made in USA

US export classification: 0A507.a

Table of Contents

- [Startpage](#)
- [English: WCP320 SIG SAUER 9MM LUGER SEMIAUTO HANDGUN Safety Instructions](#)
- [Český: Návod k bezpečnému používání WCP320 SIG SAUER 9MM LUGER SEMIAUTO HANDGUN](#)

WCP320 SIG SAUER 9MM LUGER SEMIAUTO HANDGUN Safety Instructions

Introduction

Thank you for choosing the WCP320 SIG SAUER 9MM LUGER SEMIAUTO HANDGUN. This guide provides essential safety instructions to ensure safe handling and usage of your firearm. Please read this document carefully and keep it for future reference.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Always point the firearm in a safe direction, away from yourself and others.
- Be aware of your target and what lies beyond it.
- Store the firearm securely and out of reach of children and unauthorized users.
- Regularly inspect and maintain your firearm to ensure it is in safe working condition.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- Ensure that you are familiar with the operation of your handgun before use.
- Use only the recommended ammunition (9mm Luger) as specified in the product specifications.
- Always wear appropriate eye and ear protection when shooting.
- Never attempt to modify or alter the firearm in any way.
- Do not use the firearm if it has been dropped or subjected to impact without having it inspected by a qualified gunsmith.
- If the firearm fails to fire, keep the muzzle pointed in a safe direction and wait at least 30 seconds before attempting to remove the cartridge.
- Be mindful of your surroundings and ensure that no one is in the line of fire.

Instructions for Installation and Usage

1. Loading the Firearm:

- Ensure the firearm is pointed in a safe direction.
- Open the slide and visually inspect the chamber to confirm it is clear.
- Insert a loaded magazine into the magazine well until it clicks into place.
- Pull the slide back and release it to chamber a round.

2. Firing the Firearm:

- Grip the firearm firmly with both hands.
- Align your sights with the target.
- Take a deep breath, exhale, and gently squeeze the trigger to fire.

3. Unloading the Firearm:

- Point the firearm in a safe direction.
- Remove the magazine by pressing the magazine release button.
- Pull the slide back to eject any chambered round and visually inspect the chamber to ensure it is clear.

4. Cleaning and Maintenance:

- After use, clean the firearm according to the manufacturer's instructions.
- Use only recommended cleaning supplies to avoid damaging the firearm.
- Store the firearm in a safe and secure location after cleaning.

Disposal Instructions

- Do not dispose of firearms in regular trash.
- Contact local authorities or a licensed firearms dealer for proper disposal methods.
- Ensure that the firearm is rendered inoperable before disposal.

Contact Information for Further Support

For any inquiries or concerns regarding the safety and operation of your WCP320 SIG SAUER 9MM LUGER SEMIAUTO HANDGUN, please reach out to your local authorized dealer or manufacturer.

Conclusion

Following these safety instructions will help ensure safe usage of your WCP320 SIG SAUER 9MM LUGER SEMIAUTO HANDGUN. Always prioritize safety and responsibility when handling firearms. Thank you for your attention to these important guidelines.

Návod k bezpečnému používání WCP320 SIG SAUER 9MM LUGER SEMIAUTO HANDGUN

Úvod

Tento dokument poskytuje důležité informace o bezpečném používání a údržbě pistole WCP320 SIG SAUER 9MM LUGER. Je důležité, abyste si tyto pokyny pečlivě přečetli a dodržovali je, abyste zajistili bezpečnost svou i ostatních.

Obecné bezpečnostní pokyny

- Před použitím zbraně si důkladně prostudujte návod k obsluze a bezpečnostní pokyny.
- Zbraň vždy považujte za nabitou, dokud se o tom sami nepřesvědčíte.
- Nikdy nezaměřujte zbraň na něco, co nehodláte zastřelit.
- Udržujte prsty mimo spoušť, dokud nejste připraveni střílet.
- Zbraň uchovávejte mimo dosah dětí a neoprávněných osob.
- Používejte zbraň pouze na určené účely a v souladu s platnými zákony.

Specifické bezpečnostní opatření pro použití

- Před každým použitím zkontrolujte, zda je zbraň v dobrém stavu a zda nejsou přítomny žádné viditelné poškození.
- Používejte pouze doporučené náboje (9mm Luger).
- Při manipulaci se zbraní noste ochranné brýle a sluchátka.
- Při střelbě se ujistěte, že máte dostatečný prostor a že se v okolí nenacházejí žádné osoby ani zvířata.
- Pokud se zbraň zasekne, nezkoušejte ji opravit, dokud se ujistíte, že je bezpečné se k ní přiblížit.

Pokyny pro instalaci a používání

1. Příprava na použití:

- Zkontrolujte, zda je zbraň vybitá.
- Nainstalujte grip modul Wilson Combat P320 a ujistěte se, že je správně upevněn.
- Zkontrolujte, zda je zásobník správně vložen a zajištěn.

2. Nabíjení zbraně:

- Otevřete závěr a vložte zásobník do zbraně.
- Zatlačte závěr zpět do uzavřené polohy, dokud neuslyšíte cvaknutí.
- Zkontrolujte, zda je zbraň nabitá a připravená k použití.

3. Střelba:

- Ujistěte se, že máte správný postoj a úchop.
- Zaměřte se na cíl a stiskněte spoušť hladkým pohybem.
- Po výstřelu nechte zbraň opět v bezpečné poloze, než provedete další akci.

4. Údržba:

- Po každém použití důkladně vyčistěte zbraň podle pokynů výrobce.
- Zkontrolujte, zda jsou všechny součásti v dobrém stavu a zda nevyžadují výměnu.

Pokyny pro likvidaci

- Zbraň a její součásti likvidujte v souladu s místními předpisy o odpadech a nebezpečných materiálech.
- Pokud se rozhodnete zbraň zlikvidovat, obraťte se na odborníky, kteří vám pomohou s bezpečným zničením.

Kontaktní informace pro další podporu

Pro další informace a podporu se obraťte na autorizovaného prodejce nebo servisní středisko. Ujistěte se, že máte k dispozici sériové číslo zbraně pro urychlení procesu.

Závěr

Dodržováním těchto pokynů zajistíte nejen svou bezpečnost, ale i bezpečnost ostatních. V případě jakýchkoli dotazů nebo obav se neváhejte obrátit na odborníky.