

BERETTA DT11 BLACK SPORTING TSK BARREL 34" CASE

NO IMAGE
AVAILABLE

Attributes

- Name: BERETTA USA BERETTA DT11 BLACK SPORTING TSK BARREL 34" CASE
- Manufacturer: BERETTA USA
- Product no.: 913500669
- Mfr. No.: C6A199
- Colour: Black
- Style: Shotgun

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for the BERETTA DT11 BLACK SPORTING TSK BARREL 34" CASE](#)
- [Český: Bezpečnostní pokyny pro používání produktu](#)

Safety Instruction Guide for the BERETTA DT11 BLACK SPORTING TSK BARREL 34" CASE

Introduction

Thank you for choosing the BERETTA DT11 BLACK SPORTING TSK BARREL 34" CASE. This guide provides essential safety information to ensure the safe use and maintenance of your shotgun. Please read this guide carefully before using the product to maximize your shooting experience and ensure compliance with safety regulations.

General Safety Guidelines

- Always treat your shotgun as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Do not rely on the safety mechanism; ensure the shotgun is unloaded when not in use.
- Store your shotgun in a secure location, out of reach of children and unauthorized users.
- Use only the recommended ammunition for your shotgun.
- Regularly inspect your shotgun for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.
- Attend a firearm safety course to enhance your knowledge and skills.

Specific Safety Precautions for Use

- Ensure you have a clear understanding of how to operate the shotgun before use.
- Wear appropriate eye and ear protection when shooting.
- Avoid distractions while handling your shotgun.
- Do not shoot at hard surfaces or water to prevent ricochets.
- Be aware of your surroundings and identify your target and what lies beyond it.
- If you experience a misfire, keep the shotgun pointed downrange for at least 30 seconds before attempting to open the action.
- Do not modify your shotgun or use aftermarket parts that are not approved by the manufacturer.

Instructions for Installation and Usage

1. Installation

- Ensure the shotgun is unloaded before installation.
- Follow the manufacturer's instructions for attaching or detaching any accessories.
- Check that all components are securely fastened before use.

2. Usage

- Load the shotgun only when you are ready to shoot.
- Ensure the safety is engaged until you are ready to fire.
- To fire, disengage the safety and pull the trigger while maintaining a firm grip on the shotgun.
- After shooting, engage the safety and unload the shotgun immediately.
- Clean your shotgun after each use to maintain performance and safety.

Disposal Instructions

- Dispose of any unused or expired ammunition according to local regulations.
- When disposing of the shotgun, contact a licensed firearms dealer or local authorities for proper disposal methods.

- Do not dispose of firearms in regular household waste.

Contact Information for Further Support

For any safety inquiries or support regarding your BERETTA DT11 BLACK SPORTING TSK BARREL 34" CASE, please refer to the manufacturer's contact point or authorized dealer.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable shooting experience with your BERETTA DT11 BLACK SPORTING TSK BARREL 34" CASE. Remember, safety is a shared responsibility, and your diligence is key to preventing accidents. Always prioritize safety and adhere to the guidelines provided in this document.

Bezpečnostní pokyny pro používání produktu

Úvod

Děkujeme, že jste si zakoupili brokovnici BERETTA DT11 ČERNÝ SPORTOVNÍ TSK HLAVEŇ 34" POUZDRO. Tento dokument obsahuje důležité informace o bezpečném používání vašeho produktu v souladu s Evropským nařízením o obecné bezpečnosti výrobků (GPSR). Před použitím si důkladně přečtěte následující pokyny a doporučení.

Obecné bezpečnostní pokyny

- Vždy dodržujte místní zákony a předpisy týkající se používání zbraní.
- Udržujte zbraň a její příslušenství mimo dosah dětí a zranitelných osob.
- Před každým použitím zkontrolujte, zda je zbraň v dobrém stavu a zda neobsahuje žádné poškozené části.
- Používejte pouze doporučené náboje a příslušenství.
- Při manipulaci se zbraní dodržujte zásady bezpečné manipulace se zbraněmi.

Specifické bezpečnostní pokyny pro použití

- Před střelbou se ujistěte, že je prostor kolem vás bezpečný a neobsahuje žádné osoby nebo zvířata.
- Nikdy nesměřujte zbraň na něco, co nechcete zasáhnout.
- Při střelbě noste ochranné brýle a sluchátka.
- Udržujte prsty mimo spoušť, dokud nejste připraveni vystřelit.
- Pokud zbraň selže, nezkoušejte ji otevřít ihned. Počkejte 30 sekund, než ji zkontrolujete.

Pokyny pro instalaci a používání

1. Příprava zbraně:

- Zkontrolujte, zda je zbraň prázdná.
- Nasadte příslušenství podle pokynů výrobce.

2. Nabíjení:

- Používejte pouze doporučené náboje.
- Nabíjte zbraň podle pokynů výrobce.

3. Údržba:

- Pravidelně kontrolujte a čistěte zbraň.
- Udržujte zbraň na suchém a bezpečném místě.

Pokyny pro likvidaci

- Zbraň a její příslušenství likvidujte v souladu s místními předpisy o odpadech.
- Nepokoušejte se zbraň rozebrat nebo jinak upravit bez odborného dohledu.

Kontaktní informace pro další podporu

V případě dotazů nebo obav ohledně bezpečnosti produktu se obraťte na svého prodejce nebo výrobce. Všechny produkty musí mít kontakt v EU pro bezpečnostní dotazy.

Děkujeme, že dodržíte bezpečnostní pokyny a pomáháte zajistit bezpečné používání vašeho produktu.