

BERETTA A400 XTREME STOCK MOSSY OAK GRASS BLADES

NO IMAGE
AVAILABLE

Attributes

- Name: BERETTA USA BERETTA A400 XTREME STOCK MOSSY OAK GRASS BLADES
- Manufacturer: BERETTA USA
- Product no.: 913500866
- Mfr. No.: C8C170
- Colour: Mossy Oak Grass Blades
- Features: Replacement
- Model: A400 Xtreme
- Weapon type: Beretta

Item details

US export classification: 0A501.y.1

Table of Contents

- [Startpage](#)
- [English: Safety Instructions for BERETTA A400 XTREME STOCK MOSSY OAK GRASS BLADES](#)
- [Český: Bezpečnostní pokyny pro uživatele](#)

Safety Instructions for BERETTA A400 XTREME STOCK MOSSY OAK GRASS BLADES

Introduction

Thank you for choosing the BERETTA A400 XTREME STOCK MOSSY OAK GRASS BLADES. This manual provides essential safety instructions and guidelines to ensure the safe use of your shotgun. Please read this document carefully before using the product.

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Do not place your finger on the trigger until you are ready to shoot.
- Ensure that the firearm is unloaded when not in use.
- Store the firearm in a secure location, away from children and unauthorized users.
- Use only the recommended ammunition for your shotgun.
- Regularly inspect the firearm for any signs of damage or wear.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection when shooting.
- Be aware of your surroundings and ensure that there is a safe backstop before shooting.
- Do not shoot at hard surfaces or water, as bullets can ricochet.
- Never shoot while under the influence of drugs or alcohol.
- Be cautious of other people and animals in the vicinity when shooting.
- Use the shotgun only for its intended purpose; do not modify the firearm in any way.
- If you experience a misfire, wait 30 seconds before attempting to open the action.

Instructions for Installation and Usage

- Carefully read the user manual provided with the shotgun before attempting to use it.
- To load the shotgun:
 - Ensure the safety is engaged.
 - Open the action and insert the ammunition into the magazine.
 - Close the action and disengage the safety when ready to shoot.
- To unload the shotgun:
 - Engage the safety.
 - Open the action and remove any remaining ammunition from the chamber and magazine.
- Clean and maintain the shotgun regularly to ensure optimal performance:
 - Use a soft cloth to wipe down the exterior.
 - Use a cleaning kit to clean the barrel and internal components.
 - Store the shotgun in a dry place.

Disposal Instructions

- Dispose of any unused or expired ammunition according to local regulations.
- Do not throw the shotgun in regular trash. Contact a local firearms dealer or law enforcement agency for safe disposal options.
- Ensure that all components are disposed of in an environmentally friendly manner.

Contact Information for Further Support

For any safety inquiries or concerns regarding your BERETTA A400 XTREME STOCK MOSSY OAK GRASS BLADES, please consult your local dealer or the manufacturer's customer service.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable shooting experience with your BERETTA A400 XTREME STOCK MOSSY OAK GRASS BLADES. Always prioritize safety and responsibility in all your shooting activities.

Bezpečnostní pokyny pro uživatele

Úvod

Děkujeme, že jste si zakoupili produkt BERETTA A400 XTREME STOCK MOSSY OAK GRASS BLADES. Tento návod obsahuje důležité informace o bezpečnosti, používání a údržbě vašeho výrobku. Dodržováním těchto pokynů zajistíte bezpečné používání a maximální výkon.

Obecné bezpečnostní pokyny

- Před použitím výrobku si pečlivě přečtěte všechny pokyny a bezpečnostní informace.
- Udržujte výrobek mimo dosah dětí a zranitelných osob.
- Používejte výrobek pouze k zamýšlenému účelu.
- Pravidelně kontrolujte výrobek na poškození nebo opotřebení.
- Pokud zjistíte jakékoli poškození, přestaňte výrobek používat a kontaktujte odborníka.

Specifické bezpečnostní opatření pro použití

- Při manipulaci s výrobkem dbejte na to, aby nebyl namířen na osoby nebo zvířata.
- Při použití výrobku noste vhodné ochranné pomůcky, jako jsou brýle a rukavice.
- Zajistěte, aby byl výrobek používán na stabilním a bezpečném povrchu.
- Dbejte na to, abyste se vyhnuli kontaktu s vodou nebo vlhkostí, pokud výrobek není určen pro použití v těchto podmínkách.
- Nikdy se nesnažte upravovat nebo opravovat výrobek bez odborného dohledu.

Pokyny pro instalaci a používání

1. Instalace:

- Před instalací si důkladně prostudujte pokyny a zkontrolujte všechny součásti.
- Ujistěte se, že máte všechny nástroje potřebné k instalaci.
- Instalaci provádějte na čistém a suchém místě.
- Pokud si nejste jisti instalací, obraťte se na odborníka.

2. Používání:

- Před každým použitím zkontrolujte výrobek na poškození.
- Ujistěte se, že je výrobek správně nastaven a zabezpečen.
- Po použití výrobek důkladně vyčistěte a skladujte na suchém místě.

Pokyny pro likvidaci

- Při likvidaci výrobku dodržujte místní předpisy o odpadech.
- Pokud je výrobek poškozen, zlikvidujte ho způsobem, který minimalizuje riziko pro životní prostředí.
- Nikdy nevyhazujte výrobek do běžného odpadu, pokud obsahuje nebezpečné materiály.

Kontaktní informace pro další podporu

Pro jakékoli dotazy nebo obavy týkající se bezpečnosti výrobku se obraťte na autorizovaný servis nebo prodejce. Dále doporučujeme sledovat informace o zpětném volání výrobků na platformě Safety Gate EU.

Děkujeme, že dbáte na bezpečnost a dodržujete tyto pokyny. Vaše bezpečnost je naší prioritou.