

BARREL 28 12GA 3 CHAMBER ® BERETTA A300 MOSSY OAK

NO IMAGE
AVAILABLE

Attributes

- Name: BERETTA USA BARREL 28 12GA 3 CHAMBER ® BERETTA A300 MOSSY OAK
- Manufacturer: BERETTA USA
- Product no.: 913501641
- Mfr. No.: UD7A0351P
- Colour: Mossy Oak
- Gauge: 12 Gauge
- Length: 28
- Model: A300
- Weapon type: Beretta
- Delivery weight: 1.284kg
- Shipping height: 38mm
- Shipping width: 76mm
- Shipping length: 813mm

Item details

US export classification: 0A501.c

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for the BERETTA A300 MOSSY OAK Shotgun](#)
- [Český: Návod k bezpečnému používání produktu BERETTA A300 12 GAUGE 28"](#)

Safety Instruction Guide for the BERETTA A300 MOSSY OAK Shotgun

Introduction

Thank you for choosing the BERETTA A300 MOSSY OAK Shotgun. This guide provides essential safety instructions to ensure safe handling and usage of your firearm. Please read this guide thoroughly before using the shotgun.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the shotgun pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Ensure the shotgun is unloaded when not in use.
- Store the shotgun in a secure location, out of reach of children and unauthorized users.
- Use only the correct ammunition specified for your shotgun.
- Regularly inspect your shotgun for signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- **Handling:** Always handle the shotgun with care. Avoid using it under the influence of alcohol or drugs.
- **Shooting Environment:** Only shoot in designated areas that are safe for shooting. Ensure there is a proper backstop.
- **Protective Gear:** Wear appropriate protective gear, including ear and eye protection, when using the shotgun.
- **Load and Unload:** Follow proper procedures for loading and unloading the shotgun. Always check the chamber to ensure it is empty before handling.
- **Maintenance:** Regularly clean and maintain your shotgun as per the manufacturer's instructions to ensure optimal performance and safety.

Instructions for Installation and Usage

- **Installation:**
 - Ensure the shotgun is unloaded before installation.
 - Follow the manufacturer's guidelines for any attachments or modifications.
- **Usage:**
 - To load the shotgun, open the action and insert the appropriate ammunition into the chamber.
 - Close the action securely.
 - To fire, ensure you have a clear line of sight and a safe backdrop. Aim carefully and squeeze the trigger gently.
 - After firing, keep the shotgun pointed in a safe direction and open the action to check for any remaining cartridges.

Disposal Instructions

- Dispose of any unused or expired ammunition in accordance with local regulations.
- When disposing of the shotgun, ensure it is rendered inoperable and consult local laws regarding firearm disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding your BERETTA A300 MOSSY OAK Shotgun, please consult a qualified firearms dealer or the manufacturer directly.

Conclusion

Safety is paramount when handling firearms. By following the guidelines outlined in this instruction guide, you can ensure a safe and enjoyable experience with your BERETTA A300 MOSSY OAK Shotgun. Always prioritize safety and be responsible in your usage.

Návod k bezpečnému používání produktu BERETTA A300 12 GAUGE 28"

Úvod

Děkujeme, že jste si zakoupili brokovnici BERETTA A300 12 GAUGE 28". Tento návod obsahuje důležité informace o bezpečnosti, které vám pomohou správně a bezpečně používat tento produkt. Prosím, pečlivě si přečtěte všechny pokyny a dodržujte je.

Obecné bezpečnostní pokyny

- Před použitím produktu si vždy přečtěte a porozumějte všem pokynům a doporučením výrobce.
- Ujistěte se, že produkt používáte v souladu s platnými zákony a předpisy ve vaší zemi.
- Uchovávejte produkt mimo dosah dětí a zranitelných osob.
- Při používání zbraně noste vhodné ochranné pomůcky, jako jsou ochranné brýle a sluchátka.
- Nikdy neukazujte zbraň na někoho jiného, ani když je prázdná.
- Před každým použitím zkontrolujte, zda je zbraň prázdná a zda je zajištěna.
- V případě jakýchkoli pochybností o bezpečnosti produktu se obraťte na odborníka.

Specifické bezpečnostní opatření pro použití

- Používejte pouze náboje určené pro 12 GAUGE brokovnice.
- Nikdy nepoužívejte poškozené nebo neznámé náboje.
- Před každým použitím zkontrolujte, zda není zbraň znečištěná nebo zablokována.
- Pokud dojde k selhání, nezkoušejte zbraň znovu vystřelit a nechte ji zkontrolovat odborníkem.
- Zbraň nikdy nepoužívejte pod vlivem alkoholu nebo drog.
- Udržujte zbraň v suchu a čistotě, aby se zabránilo korozi a poškození.

Pokyny pro instalaci a používání

- Před instalací se ujistěte, že máte všechny potřebné součásti a nástroje.
- Zbraň instalujte pouze podle pokynů výrobce.
- Při používání zbraně se ujistěte, že máte stabilní postoj a dobrý úchop.
- Zbraň vždy držte oběma rukama a zaměřte se na cíl.
- Po použití zbraň vždy bezpečně uložte na určené místo.

Pokyny pro likvidaci

- Zbraň a její součásti likvidujte v souladu s místními předpisy o odpadech.
- Nikdy nezahazujte náboje do běžného odpadu. Vždy je odevzdejte na určeném místě pro nebezpečný odpad.
- Při likvidaci zbraně se obraťte na odborníka nebo místní úřady, aby vám poskytly správné pokyny.

Kontaktní informace pro další podporu

Pokud máte jakékoli otázky nebo potřebujete další informace o bezpečnosti produktu, obraťte se na výrobce nebo autorizovaného prodejce.

Děkujeme, že dodržíte tyto bezpečnostní pokyny. Vaše bezpečnost je naší prioritou.